

CLEANING AND DISINFECTING

How to clean ASTARIGLAS®:

Use: Soft Microfiber cloth or Synthetic Microfiber Chamois

Cleaning agents: Soap solutions (mild soap, detergent, non-abrasive dishwashing soap).

Note: Don't use glass cleaning products (they will damage ASTARIGLAS®)

Steps:

- First, blowing the dirt and dust off the surface of ASTARIGLAS®. Avoid using your hand or a dry cloth to remove dirt; you might rub the dirt in harder and may accidentally scratch the surface of Astariglas.
- Once you have air-removed as much dirt as possible, wet down the surface. It is best to create a layer of running water over ASTARIGLAS® so the dirt will be able to just float off.
- Using a soft cloth, wash the surface with soapy water. Rinse and dry ASTARIGLAS® with another soft cloth. Don't allow ASTARIGLAS® to air dry, otherwise water spots will be left behind. Also avoid using paper towels in the cleaning process; they may be abrasive enough to cause small scratches and eventual cloudiness.

How to disinfect ASTARIGLAS®:

Use: Soft Microfiber cloth or Synthetic Microfiber Chamois, Spray bottle

Disinfectants:

1. All branded or homemade Hand-Sanitizers
2. Iso Propyl Alcohol 70% solutions
3. Hydrogen Peroxide 3-5% solutions
4. All branded household bleach products (Clorox, Dosmestos etc.), with the recommended dilution.

Steps:

- Wear disposable gloves when disinfecting surfaces. Gloves should be discarded after each use.
- Apply disinfectants to ASTARIGLAS® surface.
- Allow enough contact time (10-15 min) after applying the disinfectant. If the contact time is too brief, the surface will not be thoroughly disinfected.
- Use microfiber cloth to clean ASTARIGLAS® surface.